


Table 12" 10 Slots Spinning Prize Wheel

Instruction Manual

CONTENTS



Rotate the wooden pin while inserting it into the spring coil.
Rotate and press upward to secure the pin tightly.

STEP 1

Put pin through the wheel and fasten by M6 nut, put the Mid Bearing into the middle of the wheel.

STEP 2

Assemble the wheel to the stand bar in the following order: washer, plane bearing, washer, colored wheel with pins (washer, plane bearing, washer, backup wheel)

STEP 3

Fasten the mid Screw with butterfly nut. (Fasten or loosen the butterfly nut to make the wheel spin smoothly).

STEP 4

Put the Red triangle on the top of the stand bar.